BALLERINA

A C RELAY SW
SW ON TIMER UNIT
SHUFFLE SWITCH
CROWN WIN ARM SW
BONUS RELAY SWITCH
FUSE
SW. ON KICKER HOLE RELAY
BONUS COUNTER STEP-UP COIL
115 V. A.C.
115 V. PRIMARY
GV SECONDARY
TILT RELAY SW.
NAME LITE
TILT LITE
ON TRIP RESET
BACK BOX LITES
BUMPER LITES
SWITCH ON 1-5 WIN ARM.
5M BUMPERS
1M TO 10M BUMPERS
RED CROWN TRIP SW.
YEL. CROWN TRIP SWITCH
YELLOW CROWN
"DU" TRIP SW.
DU
"ET" TRIP SW
ET
RED CROWN
ON BONUS COUNTER
1 M DISC
10M DISC
1 M DISC
SAUCER HOLE LITES
1-8 WIN ARM
1-8 LITE

ZERO SW. ON FREE GAME UNIT
CABINET SWITCH
REPLAY
NOVELTY
CAB. SW.
INERTIA SW
TILT SW.
SHUFFLE SWITCH (DOOR)
FREE PLAY CANCEL SW.
SHUFFLE SWITCH
REPLAY
NOVELTY
SW. ON TILT RELAY
INERTIA SWITCH IN BACK BOX.
FUSE
50 V. SECONDARY
SHUFFLE ARM SWITCH
KICKER HOLE SW.
SW. ON TIMER UNIT
1-8 WIN ARM SWITCH
SW. ON KICKER HOLE RELAY
SW. ON 50M RELAY
1-8 WIN RLY. SW.
10M STEP UP ARM SWITCH
ON 10M DISC
1M RELAY SW.
5 PULSE CAM SW. ON TIMER UNIT
CYCLE RELAY SWITCH
-1 SW. ON 10M
ON 1M STEP UP ARM
1M DISC
50M RELAY SW.
SW. ON TIMER UNIT
SW. ON BONUS ESC.
DUET WIN ARM SW.
1-8 WIN ARM SW.
1M & 10M
SW. ON TIMER UNIT
50M RELAY SW.
CYCLE RELAY SW.
STRT WIN ARM SW.
TO Y
BONUS RELAY SWITCH
20Ω
RED R.O. SW. YELLOW
R.O. SW.
"DU" ROLL OVER SW.
"ET" R.O. SW.
BONUS RELAY SW.
SW. ON 50 M RELAY
SW. ON KICK HOLE RELAY
SWITCH'S CLOSED BY KICKER
TOP SAUCER HOLE SW.
5 HOLE SW.
-1 SW. 10 M UNIT
SWITCH ON TIMER UNIT
CYCLE RELAY SWITCH
BONUS HOLE SW. 3
DUET WIN ARM SW.
SW. ON TIMER UNIT
ON BONUS RESET LOCK
SHUFFLE SWITCH
TILT RELAY SW.
FLIPPER SWITCHES (IN CABINET)
OPEN AT ZERO
CLOSED AT ZERO
CLOSED BY BONUS KICKER
SW. ON KICKER HOLE RELAY
1-8 WIN ARM SWITCH
SAUCER AND 5M HOLE KICKER COIL
KICKER HOLE COIL
SWITCH ON TIMER UNIT
MOTOR
BONUS COUNTER ESCAPEMENT COIL. 28E18
BONUS KICKOUT COIL E-184-18
BONUS RESET LOCK COIL
FLIPPER COIL 26A10
ANTI-CHEAT RELAY 90Ω
COIN CHUTE COIL 90Ω
REPLAY ESC. 28R18
REPLAY METER
TILT RLY.
10M RESET COIL 28R18
KICKER HOLE RELAY
1-8 WIN RELAY COIL
50M RELAY
RE-PLAY STEP UP COIL 24A4
10M STEP UP COIL 26H10
1M STEP UP COIL 26A7
10M GONG
1M RELAY
BONUS RELAY
CYCLE RELAY
ORANGE

SWITCH SYMBOLS
NORMALLY OPEN
NORMALLY CLOSED
SINGLE POLE DOUBLE THROW
NORMALLY OPEN (THREE LEAF)
BUMPER CONTACT

20 PT. PANEL TO BACK BOX
BLUE GRAY (X1) (12)
YELLOW BL.-WH. (82) (3)
GREEN YEL.-RED (183) (4)
WHITE GRN.-WH. (X84) (5)
BROWN WH.-GRN. (X45) (86)
ORANGE BR.-WH. (X64) (7)
BLACK OR.-GRN. (X7) (88)
RED-GRN. BLK.-YEL. (X38) (29)
GRN.-RED GRN.-BLK. (X29) (134)
WH.-RED SL.-BLK. (X10) (135)

18 PT. PANEL TO BACK BOX
RED BL.-WH. (X82) (81)
WHITE YEL.-RED (X23) (85)
ORANGE GRN.-WH. (X44) (87)
BLACK OR.-GRN. (X167) (8)
RED-GRN. GRN.-BLK. (X9) (83)
RED-BLK. SL. BLK. (X110) (310)
RED-WH. (11)
BLUE-RED (32)
GR.-RED (614)

10 PT. PANEL TO CABINET
GREEN WH.-GRN. (X45) (4)
WHITE OR.-GRN. (X7) (5)
ORANGE BLK.-YEL (X48) (7)
RED-GRN. GRN.-BLK. (X9) (9)
BLUE-RED (12)