

Amendment

RIVERBOAT GAMBLER OPERATIONS MANUAL

The following are changes that have occurred since the RIVERBOAT GAMBLER OPERATIONS MANUAL was printed. Keep this Amendment with your RIVERBOAT GAMBLER OPERATIONS MANUAL.

Page 21

Adjustment #47 REDEMPTION should read,

IMPORTANT!

EQUIPPING AN ELECTRONIC GAME WITH A REDEMPTION DEVICE MAY BE PROHIBITED UNDER APPLICABLE LAWS. CHECK WITH LOCAL AUTHORITIES CONCERNING THESE LAWS PRIOR TO INSTALLING ANY TICKET OR OTHER REDEMPTION DEVICE.

47 REDEMPTION There is a 50 ticket limit per player.

If Replay Adjustment 6 is set to COIL, the operator can choose (via the Start button), any of the five ticket Redemption modes (Note: All modes will dispense a ticket in place of any normal awarded credit). The five choices are:

Chip Level—— One ticket awarded for each set number of chips (choices are: 100, 500 & 1000).

Misc——— Set # of tickets awarded per feature (Jackpot=5, Special=20, Roulette Win=1, Casino Letters=1, 1 Mill.=1).

Jackpots —— One ticket awarded for each Jackpot scored.

Features —— One ticket awarded for each feature completed.

Credits —— One ticket awarded in place of each credit earned by player.

Page 10

The Game-specific Adjustment Table changed to the following.

RIVERBOAT GAMBLER Game-specific Adjustments Table

Adjustment Item (Lower)	Descriptive Phrase (Upper Display)	Factory Setting (Lower)		
		Domestic (US/Can.)	French	W Ger/ European
Ad	31	Attract Mode Sounds	Off	Off
	32	Special %	3%	3%
	45	Jackpot %	Normal	Normal
	46	No Buttons	Off	Off
	47	Redemption	500 Chips	N/A
	48	Jet Speech	Normal	Normal
	51	Buy-in	Off	Off
	52	Replay Boost	3 Million	3 Million

Page 15

Adjustment #02 STARTING REPLAY LEVEL (OR REPLAY LEVEL 1) should read.

For AUTO REPLAY (refer to Ad 01), the initial Factory Setting is listed in the Game Adjustment Table. The range of this setting is 2, 000, 000 through 9, 800, 000 (by increments of 100, 000 with AUTO-UP or decrements of 100, 000 with MANUAL-DOWN).

For FIXED REPLAY, the operator can enter the value to be used for the fixed replay score level via the Start Button. The range of this setting is: OFF ; 200, 000 through 9, 900, 000 (by increments of 100, 000 with AUTO-UP and decrements of 100, 000 with MANUAL-DOWN).

Adjustment #03 REPLAY LEVELS (OR REPLAY LEVEL 2) should read,

For AUTO REPLY (refer to Ad 01), this is the number of replay levels in a game. The option range is one, two, three, or four replay level(s). When the operator chooses two replay levels, RIVERBOAT GAMBLER automatically adjusts the second replay level to be twice the value selected for Ad 02, the starting replay level. Choosing three or four replay levels automatically adjusts their replay levels to three or four times the Ad 02 value. If the replay level exceeds 9, 800, 000 the replay level is not used.

Page 20

Adjustment #45 JACKPOT PERCENT should read,

The operator can specify (via the Start button) the percentage limit for the Jackpot feature. The range of the setting is 5% (Conservative) through 50% (Liberal) , and Normal (Jackpot is awarded normally random).

Page 22

Adjustment #52 REPLAY BOOST should read,

The operator can choose (via the Start button) the MAXIMUM amount the replay score can be temporarily boosted EACH time a player reaches or exceeds the replay score. Note, that the boost will normally raise the replay score to the next million above the highest players score, with this game adjusts limitation. This temporary boost is canceled when CREDITS=0, pressing the advance button, or when a player inserts another coin. Note, this is turned off in FREE PLAY. The range of settings are:

OFF - DO NOT temporarily boost the replay score.

1, 000, 000 to 50, 000, 000 - The maximum amount the replay score can increase for a game, until it is canceled.

Page 24

The Preset Game Adjustment Table for French Game changed to the following,

RIVERBOAT GAMBLER
Preset Game Adjustments Table for French Games

Adj #	Adj Description	French 1	Ad 53	French 2	Ad 54	French 3	Ad 55	French 4	Ad 56	French 5	Ad 57	French 6	Ad 58
33	Ex Ball Percent	25 %		20 %		70 %		25 %		25 %		25 %	
60	Install 5 Ball	N/A		N/A		N/A		N/A		N/A		Yes	

WHEN ORDERING PLAYFIELD PLASTICS USE 50007 NUMBER INSTEAD OF 5007 NUMBER.