

ROCKET III

MODEL #800 (Replay)

PARTS LIST

	<u>PART NO.</u>		<u>PART NO.</u>
<u>MISCELLANEOUS:</u>		<u>ASSEMBLY COILS:</u>	
Transformer	E-122-95	Open Flippers	C-7800-334
Score Motor	E-119-354	Close Flippers	E-184-239
Spinning Bumper Motor	E-119-358	Left Flipper	E-184-190
Trip Bank Motor	E-119-362	Right Flipper	E-184-190
		#1 Thumper Bumper	E-184-190
<u>TRIP RELAY COILS:</u>		#2 Thumper Bumper	E-184-190
Game Over	E-184-155	#3 Thumper Bumper	E-184-190
Start	E-184-155	#4 Thumper Bumper	E-184-190
Reset Motor	E-184-155	Ball Return Kicker	25-A-7
#6 Mushroom Bumper	E-184-155	Left Slingshot	25-A-7
#5 Mushroom Bumper	E-184-155	Right Slingshot	25-A-7
#4 Mushroom Bumper	E-184-155	Free Ball Gate	E-184-204
#3 Mushroom Bumper	E-184-155	Sounder	27-R-11
#2 Mushroom Bumper	E-184-155	Bell	31-0-55
#1 Mushroom Bumper	E-184-155	Special Kicker	E-184-235
		<u>UNIT COILS:</u>	
<u>KK RELAY COILS:</u>		Name (Step-Up)	26-GG-10
Yellow Mushroom Bumper	C-7800-3316	Name (Reset)	28-R-15
Red Mushroom Bumper	C-7800-3316	Ball Count (Step-Up)	E-184-205
50 Point	C-7800-331	Ball Count (Reset)	28-R-15
Series	C-7800-351	Replay (Step-Up)	26-GG-9
Close Flipper	C-7800-3314	Replay (Reset)	28-R-15
Match	C-7800-334	0-9 Match	E-184-205
Ball Return	C-7800-331	1-9 Score	E-184-206
Tilt	C-7800-332	10-90 Score	E-184-206
Anti-Cheat	C-7800-3312	100-900 Score	E-184-206
Credit	C-7800-331	1000-9000 Score	E-184-206
3rd Coin Chute	C-7800-331	Advance	E-184-206
2nd Coin Chute	C-7800-331	Alternator	E-184-206
1st Coin Chute	C-7800-331		
Reset	C-7800-331	<u>UNIT CONTACT DISC'S:</u>	
100 Point	C-7800-333	Name	W-1077-3
10 Point	C-7800-333	Ball Count	W-1043-4
1 Point	C-7800-333	0-9 Match	W-1034-9
Advance	C-7800-331	1-9 Score	A-2212-7
Free Ball	C-7800-332	100-900 Score	A-2212-7
1-3 Thumper Bumper	C-7800-334	1000-9000 Score	A-2212-7
2-4 Thumper Bumper	C-7800-334	Advance	A-2212-7
Special	C-7800-3312		

Rocket III #800 Parts List continued

	<u>PART NO.</u>
<u>UNIT WIPER ASSEMBLIES:</u>	
Name	AS-1046-505
Ball Count	AS-1046-500
0-9 Match	AS-1046-501
1-9 Score	A-1618-3
100-900 Score	A-1618-3
1000-9000 Score	A-1618-3
Advance	A-1618-3

<u>SCORE MOTOR SWITCHES:</u>	
Cam 1	SW-240-5
Cam 2	SW-100-459
Cam 3	SW-300-62
Cam 4	SW -200-140
Cam 5	SW -300-62
Cam 6	SW-100-459
Cam 7	SW- 1 10-149
Cam 8	SW-200-140
Cam 9	SW-200-140
Cam 10	SW-040-12
Cam 11	SW-100-459

<u>TRIP RELAY BANK SWITCHES:</u>	
(Switches listed left to right from wiring side)	
Carry-Over Cam	SW-110-158
Game Over	SW-121-19
Start	SW-302-3
Start	SW-210-73
Reset Motor	SW-110-156
#1 Mushroom Bumper	SW-011-38
#2 Mushroom Bumper	SW-011-38
#3 Mushroom Bumper	SW-011-38
#4 Mushroom Bumper	SW-003-9
#5 Mushroom Bumper	SW-003-9
#6 Mushroom Bumper	SW-003-9
Carry-Over Cam	SW-210-72