

C - Conservative
M - Medium
L - Liberal

RUBBER RINGS

R1	7A-120-100	1" DIA.
R2	7A-120-031	5/16" DIA.
R3	7A-120-150	1-1/2" DIA.
R4	7A-120-200	2" DIA.
R5	7A-120-250	2-1/2" DIA.
R6	7A-125	
R7	7A-121 W	Flipper

GUIDE WIRE & ROLL OVER WIRE

W1	6A-219
W2	6A-220
W3	A-473
W4	A-474
W5	6A-215
W6	A-150
W7	A-149
W8	A-383
W9	6A-101

PLAYFIELD PLASTIC SHIELDS

TOP ARCH SET 13C-102-1L & M
STARS SET 13C-103-1 to 7

MISCELLANEOUS PARTS

1. BALL GATE, LEFT A-104-L
2. BALL GATE, RIGHT A-104-R
3. ROLL OVER BUTTON ASS'Y A-181
4. BANK TARGET ASS'Y D-393-3
5. SPIN TARGET ASS'Y B-102-2
6. BALL GUIDE POST 2A-200
7. THUMPER CAP 13A-12
8. FLIPPER & SHAFT A-192
FLIPPER 4B-122-W
9. INSTRUCTION PLATE 14B-1-2
10. SHOOTER GUAGE 14B-2-2
11. TARGET ASS'Y A-461
12. TOP ARCH RAIL 1B-107
13. BALL GATE ASS'Y A-471




FIGURE 3. STARS PLAYFIELD PARTS