

C - Conservative
M - Medium
L - Liberal

RUBBER RINGS

R1	7A-120-250	2-1/2" DIA.
R2	7A-120-031	5/16" DIA.
R3	7A-120-200	2" DIA.
R4	7A-120-350	3-1/2" DIA.
R5	7A-120-125	1-1/4" DIA.
R6	7A-120-150	1-1/2" DIA.
R7	7A-121	FLIPPER
R8	7A-125	

GUIDE WIRE & ROLL OVER WIRE

W1	A-149
W2	A-383
W3	6A-101-C
W4	6A-206
W5	6A-205
W6	6A-204
W7	6A-101-B
W8	6A-210
W9	6A-101-D
W10	6A-139
W11	A-150

PLAYFIELD PLASTIC SHIELDS

TOP ARCH SET 13C-100-1L & M
STINGRAY SET 13C-102-1 TO 7

MISCELLANEOUS PARTS

1. BALL GATE LEFT A-104-L
2. ROLL OVER BUTTON ASS'Y A-181
3. BALL GATE RIGHT A-104-R
4. BANK TARGET ASS'Y D-393-5
5. SPIN TARGET ASS'Y B-102-1
6. BALL GUIDE POST 2A-200
7. THUMPER CAP 13A-6-1
8. FLIPPER & SHAFT A-192
FLIPPER 4B-122-W
9. INSTRUCTION PLATE 14B-1-2
10. SHOOTER GUAGE 14B-2-1
11. TARGET ASS'Y A-461
12. TARGET ASS'Y A-461-1
13. GUIDE RAIL 1A-591
14. GUIDE RAIL 1A-586
15. TOP ARCH RAIL 1B-107




FIGURE 2. STINGRAY PLAYFIELD PARTS