


C - Conservative
M - Medium
L - Liberal



R1-7A-120-031	R4-7A-120-100
R2-7A-121-W	R5-7A-120-300
R3-7A-125	

W1-6A-101-G	W6-4A-110-G
W2-6C-230	W7-4A-121-R
W3-A-149	W8-A-581
W4-A-383	W9-4A-224-R
W5-4A-110-R	

TOP ARCH SET 13C-114-1R-&1L
GALAXY SET 13C-114-2-TO-8 (P1 TO P8)

1. 4-BANK TARGET D-548-4A
2. TARGET ASSEMBLY A-469-Y-BL-B
3. THUMPER CAP 13A-12-5
4. ROLLOVER BUTTON 4B-275
5. BALL GATE A-104-R2
6. 1-WAY GATE ASS'Y A-644
(WIRE FORM 6A-257)
7. SPIN TARGET ASS'Y A-563-10
(TARGET & WIRE ONLY 14A-7-9)
8. FLIPPER & SHAFT ASS'Y A-193
9. BALL GUIDE POST 2A-200
10. INSTRUCTION PLATE 14B-3-2
11. SHOOTER GAUGE 14A-2-5

Page 13