

INSTRUCTIONS

- Bonus X:** Completing B-A-RR or A-C-O-R-A target bank in sequence advances Bonus X. Completing both banks advances Super Bonus X. Spotting Super 5X lights outlane Special lamps.
- Top Lanes:** Spotting 1-2-3 advances upper left eject hole lamps — 30,000, 60,000, 90,000. Spotting 4-5-6 advances upper right Bull's-Eye target lamps — 20,000, 40,000, Extra Ball. Spotting 1-2-3-4-5-6 lights top eject hole to collect bonus. Right flipper Lane Change™ switch rotates 1-2-3 lamps, left flipper Lane Change™ switch rotates 4-5-6 lamps.
- Target Bonus:** Target Bonus resets when scored or, with bonus lamps lined up, resets when scored twice.
- Multi-Ball™:** Completing B-A-RR or A-C-O-R-A target bank spots eject hole lock lamps for 2- or 3-ball Multi-Ball play. With both lamps lit, lock ball in top left eject hole first for 3-ball chance.
- Extra Ball:** Making upper right Bull's-Eye target when lit awards Extra Ball, Bonus Ball, or 100,000 points.

- Special awards 1 CREDIT
- Beating highest score awards 3 CREDITS
- Matching scores 1 CREDIT