

GAME ADJUSTMENTS

PLAYFIELD PANEL POST ADJUSTMENTS:

The playfield panel has posts at bottom of panel that can be moved at operators discretion to increase or decrease games scoring potential. A card showing posts in conservative position will be found in game.

BELL ADJUSTMENT PLUG:

Located on back box insert. This plug provides positions to ring bell for 10 point scores, 100 point scores, or both 10 and 100 point scores.

HI SCORE ADJUSTMENT PLUG:

Located on back box insert. This plug provides positions at which replays or added balls* can be awarded for hi-scores. Recommended plug settings corresponding to score cards shipped with game, will be found on hi score adjustment chart inside back door.

SUPER SCORE ADJUSTMENTS:

Located at 1st and 2nd player super score disc. These jumper wires with push on type terminals provide for awarding replays, added balls* or points at super scores of 3 to 8.

SCORING FEATURE ADJUSTMENT PLUG:

Located on mounting board. This plug provides positions to award replays or added balls* for pre-set hi scores, and to award replays, added balls* or points for pre-set super scores and match number.

BALLS PER GAME ADJUSTMENT PLUG:

Located on mounting board. This plug provides positions for 7 ball, 5 ball or 3 ball operation.

MATCH FEATURE ADJUSTMENT PLUG:

Located on mounting board. This plug provides positions to operate game with (on) or without (off) match number feature.

2nd & 3rd COIN CHUTE ADJUSTMENT PLUG:

Located on mounting board. This plug provides positions to give 2 to 6 plays per coin thru 2nd and 3rd coin chutes.

1st COIN CHUTE ADJUSTMENT PLUG:

Located on the alternator unit on mounting board. This plug provides positions to give 1 play per coin or 1 play per two coins thru 1st coin chute.

*When Add-A-Ball conversion kit (K-313-1) is used.