

"T H I N G"

I M P O R T A N T

To shorten playing time adjust contacts on OUT HOLE GATE CONTR
Game is set to allow 3 steps on GATE CONTROL STEP-UP UNIT, bef
GATE will open.

By bending top contact down, GATE can be set to open at 2 steps
instead of 3 steps. This means that GATE will open at 200,000 in
300,000 on each ball.

Similar adjustment can be made to open GATE at 100,000.

CHICAGO COIN MACHINE COMPANY

"T H I N G"

I M P O R T A N T

To shorten playing time adjust contacts on OUT HOLE GATE CONTROL.

Game is set to allow 3 steps on GATE CONTROL STEP-UP UNIT, before GATE will open.

By bending top contact down, GATE can be set to open at 2 steps instead of 3 steps. This means that GATE will open at 200,000 instead of 300,000 on each ball.

Similar adjustment can be made to open GATE at 100,000.

CHICAGO COIN MACHINE COMPANY