

GENERAL INSTRUCTIONS FOR "WHEELS II"

INSTALLATION:

Fasten four provided leg levelers to bottom of cabinet. The power is controlled by a switch located on the lower back wall of the cabinet. Plug into A.C. only, 115 volts, 60 cycles.

EXTENDED PLAY ADJUSTMENT SWITCH:

Located on Logic Unit (PC 594-904) and is adjustable from 300 to 600 points. See adjustment instructions located in back box area.

1ST AND 2ND PLAYER VOLUME CONTROL POTS:

Located on Logic Unit (PC 594-904) volume may be set by rotating pots as indicated on instructions in back box area.

GAME TIME POT:

Located on Logic Unit (PC 594-904) and may be increased by rotating pot as indicated on instructions in back box area.

ANTI-STATIC ADJUSTMENT POT:

Located on Logic Unit (PC 594-904) this pot is provided so that each game may be adjusted to the locations static conditions. Rotate pot as indicated to increase sensitivity. This control puts unit in a game-over condition when a static shock is applied.

VOLTAGE CONTROL POT:

Located on Power Supply Unit (PC 594-903) this voltage is pre-set at the factory and should not be tampered with. In event the Power Supply must be changed, adjust voltage to 5 volts by rotating pot as indicated on Power Supply.

OBJECT CAR ACCELERATOR POT:

Located on Logic Unit (PC 594-904) this pot is pre-set at the factory and should not be tampered with.

TRACK SPEED POT:

Located on Logic Unit (PC 594-904) this pot controls the speed at which the track runs. This control is pre-set at the factory and should not be tampered with.