

WOZ / HOBBIT Monitor Repair Flowchart

Wells Gardner 27" LED W/SAMSUNG PANEL VGA/DVI Model WGF2759-SFBS25D


Created by: Dave Okert (Dok is the Lead Repair Medic for the Northwest Pinball and Arcade Show in Tacoma, WA.)

Errors and Omissions can be submitted to dokert@comcast.net

WARNING

DO NOT press the power button on the front of the Monitor if your monitor fails to produce a picture, you may cause further damage to the monitor or the Game CPU Motherboard. Specifically, damage may occur to the DVI port on the Game CPU Motherboard by pressing the power button on the front of the monitor. The monitor controls are pictured below.

It is Recommended that the backglass and the playfield glass be removed for troubleshooting and repairs of the monitor. Tools to have on hand are: 1/4" nut driver, #1 Phillips screwdriver, DMM, known working computer monitor with both VGA and DVI connections available, known good VGA and DVI cables.



WOZ / HOBBIT Monitor Repair Flowchart

Wells Gardner 27" LED W/SAMSUNG PANEL VGA/DVI Model WGF2759-SFBS25D

Created by: Dave Okert (Dok is the Lead Repair Medic for the Northwest Pinball and Arcade Show in Tacoma, WA.)

Errors and Omissions can be submitted to dokert@comcast.net

WARNING

DO NOT press the power button on the front of the Monitor if your monitor fails to produce a picture, you may cause further damage to the monitor or the Game CPU Motherboard. Specifically, damage may occur to the DVI port on the Game CPU Motherboard by pressing the power button on the front of the monitor. The monitor controls are pictured below.

It is Recommended that the backglass and the playfield glass be removed for troubleshooting and repairs of the monitor. Tools to have on hand are: 1/4" nut driver, #1 Phillips screwdriver, DMM, known working computer monitor with both VGA and DVI connections available, known good VGA and DVI cables.

