

FOUR KINGS TM SWITCH SETTING

TIME SETTINGS

SW #1	SW #2	TIME	AFTER DISCARD
ON	ON	60	50
OFF	ON	70	50
ON	OFF	80	50
OFF	OFF	90	50

COIN SETTINGS

SW #3

ON

1 COIN 1 CREDIT = (1 HAND)

OFF

1 COIN 2 CREDITS = (2HANDS)

DISCARD SETTINGS

SW #8

OFF

DISCARD 3 CARDS

ON

DISCARD 4 CARDS

NOTE

SWITCHES 4, 5, 6, & 7 ARE NOT USED AND SHOULD BE OFF!!!