

"WILD CAT"

Control Plug Settings

As the machine leaves the factory, the adjustment plugs are in the white positions. This is the NORMAL setting and will be found to be entirely satisfactory at the average location.

NOTE: Do NOT remove control plugs and leave them out, as this will make the machine inoperative.

PERCENTAGE

(P. ADJ. PLUG)

RED	Liberal
WHITE	Normal
BLACK	Conservative

RABBITS ON NO. 1 FLASHER

(R. ADJ. PLUG)

RED	3 Rabbits
WHITE	2½ Rabbits
BLACK	2 Rabbits

WILD CAT ADJUSTMENT

(W.C. ADJ. PLUG)

WHITE	Normal
BLACK	Conservative

Games, Inc.

Manufacturers

2950 N. CAMPBELL AVENUE

CHICAGO 18, ILLINOIS

BULK RATE
U. S. POSTAGE
PAID
CHICAGO, ILLINOIS
PERMIT NO. 427

FORM 3547 REQUESTED